

GEWA Digitalpiano

UP-Series

Firmware Update
UP360G / UP380G / UP380G WK

This manual will help you to do an update at your GEWA digitalpiano.

Supported Models:

UP360G, UP380G, UP380G WK

You will need a USB stick and the appropriate firmware to complete this update.

Update / Installation

Step 1

Save the firmware on your USB stick and connect it to your digital piano.

Step 2

Push and hold down the two keys “lowest a and c-sharp” and switch on the digital piano to enter the update mode.
(see picture)



Step 3

Select the firmware file with the "up / down" cursor buttons, than press the "left" cursor button to start the update process.

The update should only take a few seconds. Please do not switch off the digital piano during the process!

Step 4

The update is completed as soon as the progress bar has expired and the display shows you the update file again. Now you can turn off the piano by holding down the on / off switch. (This may take a moment)

Step 5

All updates will take effect when the digital piano is restarted